



# Garmin Dezl 760LMT Screen Ribbon Cable Replacement

Prerequisite Only

Written By: Ryan Williams





## TOOLS:


- [Metal Spudger](#) (1)
  - [Anti-Static Wrist Strap](#) (1)
-

## Step 1 — Screen Ribbon Cable



- Lift the screen opposite where the "GARMIN" logo is located. Remove the clear tape holding the ribbon cable to the motherboard.

## Step 2



- Find and lift the small grey hinge at the end of the ribbon cable.

⚠ When handling the motherboard, make sure to wear an anti-static wrist strap.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 01:09:56 PM.